

Credo ProMed™ Product Line



Thermally Protected Medical Transporters

Designed specifically for the “always ready to go” needs of pharmaceutical reps and first responders the Crēdo PROMED™ product line currently consists of three different sized temperature-controlled portable medical transport bags that thermally protect the integrity of valuable pharmaceutical samples and medical supply payloads for up to 72 hours.

The outer bag is constructed of highly durable ballistic nylon fabric with attractive design finishes for the most discriminative professional. The patented Crēdo TIC™ with phase change material and VIP components contained within are qualified to consistently protect medical materials such as blood, platelets and commercial bio-pharma product samples within two ranges (2-8°C and 15-25°C) for up to 72 hours.

Product Specifications

SERIES 4 (2-8°C)

SERIES 22 (15-25°C)

Payload Volumes:

2, 4 and 8 Liters

Thermal Performance:
up to 72 Hours

Outer Container:
Ballistic Nylon Fabric
with high quality faux
leather trim accents
and durable web
strapping and
secure buckles

Color Options:
Standard Tan*

*Other colors
available upon
request



Credo ProMed™ Series

Pelican BioThermal, in response to an identified need by its pharmaceutical clients looking for a dependable, easy to use “load and go” thermal protection soft-side Rep bag - minus the mess and inconvenience of ice or gel pack insulation.

The Crēdo ProMed™ temperature-controlled portable medical transport solutions were designed with the needs of sales representatives, first responders and medical couriers in mind. The same patented passive thermal protection technology that is part of the Credo Cube™ product family is now available in three convenient payload volume sizes. These hand portable, highly durable and convenient to use soft-sided bags offer:

- Easy preconditioning of the TIC™ system panels makes getting on with your day or responding to an emergency call simple, fast and consistently reliable. Once the TIC system panels are staged and properly placed inside the VIP (vacuum insulation panels) assembly, simply insert payload content and you are on your way.
- Rugged, yet attractive bag finishes include sturdy, supportive interior side panels, double-stitched seams, reinforced protective corners, durable buckle straps, comfortable padded shoulder strap and a water and soil resistant protective bottom panel.
- A sleek, clear view pocket keeps your business essentials readily accessible. A sturdy elastic back strap designed to slip effortlessly over telescoping handles enabling secure transport on top of wheeled bags.

PELICAN BIOTHERMAL, LLC
Sales & Operations Headquarters
3020 Niagara Lane North
Plymouth, MN 55447 USA
1.877.537.9800
www.pelicanbiothermal.com
B9_V6_0915

All trademarks are registered and/or unregistered trademarks of Pelican BioThermal LLC, its parent, subsidiaries and/or affiliates.

ISO 9001-2008 Certification
ISO 14001-2004 Certification
OHASA18001-2007 Certification
ISO 17025 Certification



2 Liter Payload

Interior Dimensions:
6 in x 5 in x 4.25 in
152.4 mm x 127 mm x 108 mm

Exterior Dimensions:
10.125 in x 9.25 in x 8.25 in
257 mm x 235 mm x 210 mm

Tare Weight:
7.7 lbs. 3.5 kg

ISTA 7D Summer Performance
46.55 hrs
ISTA 7D Winter Performance
75.67 hrs



4 Liter Payload

Interior Dimensions:
5.9 in X 5.9 in X 5.9 in
149 mm x 149 mm x 149 mm

Exterior Dimensions:
11.5 in x 11.25 in x 11 in
292 mm x 286 mm x 279 mm

Tare Weight:
12.2 lbs. 5.5 kg

ISTA 7D Summer Performance
73.25 hrs
ISTA 7D Winter Performance
110.58 hrs



8 Liter Payload

Interior Dimensions:
11.1 in x 6.5 in x 6.5 in
282 mm x 165 mm x 165 mm

Exterior Dimensions:
16 in x 11.25 in x 11.25 in
406 mm x 286 mm x 286 mm

Tare Weight:
18.0 lbs. 8.2 kg

ISTA 7D Summer Performance
73.80 hrs
ISTA 7D Winter Performance
110.58 hrs

