



## CRÊDO CUBE™ SERIES 22

Superior thermal protection in a convenient mid-size container.

The Crêdo Cube™ is a passive and reusable shipper qualified to hold chilled medical materials at a safe temperature for up to five days. This system is ideal for reducing shipping costs or for circumstances in which unexpected delays may occur.

Modular TIC™ (Thermal Isolation Chamber) walls with integrated PCM (Phase-Change Material) and VIPs (Vacuum Insulated Panels) makes conditioning in a freezer for year-round shipping easy and allows effortless packing and storage.

## WHY CHOOSE CRÊDO™ SYSTEMS?

- The most trusted and well recognized brand of high-performance reusable shippers with the largest number of sizes and temperature ranges available
- Unique TIC™ walls contain PCM and completely enclose the temperature-sensitive payload ensuring consistently stable performance
- Crêdo™ shippers are highly durable, lightweight, and provide an optimum volume ratio of interior payload space for your products - allowing you to ship more product in fewer containers, reducing distribution costs



## ENHANCE YOUR CRÊDO™ SYSTEMS

- **Crêdo ProEnvision™**: Easy-to-use, secure, web-based asset tracking software and global service centers available to assist customers and maximize their return on investment

## CRÊDO CUBE™

### DURATION

96 - 144 Hours

### SERIES 22 CONTROLLED

(15°C to 25°C)

### VOLUME

3L, 4L, 8L, 10L, 12L, 16L,  
28L, 42L, 56L

### SERIES 22 UNIVERSAL

(15°C to 25°C)

### VOLUME

9L, 24L, 49L

## CRĒDO CUBE™ SERIES 22 CONTROLLED & UNIVERSAL

### Controlled

Single PCM TICs designed for trips in controlled shipping lanes with reliable certainty of temperature during the trip duration.

### Universal

Double-bracketed PCM TICs specially designed for trips in shipping lanes with a variety of temperatures, such as seasons with large changes in warm or cool conditions or trips across the Equator.



## CRĒDO™ SERIES 22 CONTROLLED 15°C TO 25°C

Payload Size	Exterior Dimensions - Inches	Interior Dimensions - Inches	Tare Weight - lbs
<b>Single Wall VIP, White Plastic Corrugate</b>			
3L	13 x 11 x 11	5 x 5 x 5	14
4L	13 x 11 x 11	6 x 6 x 6	12
8L	18 x 11 x 12	11 x 7 x 7	17
10L	15 x 14 x 14	9 x 9 x 9	24
12L	15 x 14 x 14	9 x 9 x 9	22
16L	17 x 15 x 15	10 x 10 x 10	25
28L	18 x 17 x 17	12 x 12 x 12	36
42L	24 x 17 x 17	18 x 12 x 12	46
<b>Single Wall VIP, Kraft Box</b>			
56L	21 x 20 x 20	15 x 15 x 15	54
<b>Nested VIP, White Plastic Corrugate</b>			
4L	15 x 14 x 14	6 x 6 x 6	20
12L	18 x 17 x 17	9 x 9 x 9	36
<b>Nested VIP, Kraft Box</b>			
28L	21 x 20 x 20	12 x 12 x 12	56
<b>Double Wall VIP, White Plastic Corrugate</b>			
16L	18 x 17 x 18	10 x 10 x 10	37

## CRĒDO™ SERIES 22 UNIVERSAL 15°C TO 25°C

Payload Size	Exterior Dimensions - Inches	Interior Dimensions - Inches	Tare Weight - lbs
<b>Single Wall VIP, White Plastic Corrugate</b>			
9L	15 x 14 x 14	8 x 8 x 8	25
24L	18 x 17 x 17	11 x 11 x 11	41
49L	21 x 20 x 20	14 x 14 x 14	60

**Superior Performance**  
ensuring complete  
product integrity

**Small and Light**  
significantly reducing  
distribution costs

**Crêdo ProEnvision™ and  
Service Centers**  
support reclamation  
and re-use

FOR MORE INFORMATION ABOUT PELICAN BIOTHERMAL PRODUCTS, PLEASE CONTACT:

INFO@PELICANBIOTHERMAL.COM T: +1 763 412 4800 PELICANBIOTHERMAL.COM

ISO17025, ISO9001-2008 Accredited

Golden Hour™, TIC™, Crêdo™, Crêdo Cube™, Crêdo ProEnvision™, Crêdo Xtreme™, Crêdo DURACUBE™, Crêdo ProMed™, Sherpa™ Systems, Chronos™ Express, Chronos™ Advance and CoolPall™ Vertos are registered trademarks of Pelican Products, Inc., its subsidiaries and/or affiliates.



©2017 PELICAN BioThermal all rights reserved.